




# TENCEL<sup>®</sup> in mattresses

THE NEW AGE FIBER

---



# Contents:

---

- Sleep studies
- Skin compatibility
- Lenzing research on knitted mattress tickings:
  - Pilling behavior
  - Moisture management and physiological attributes
- Hygiene attributes
- Electrostatic behavior

# Independent scientific studies: Better sleep with TENCEL®

---

## Studies prove the TENCEL® functions

- 1) Comparison of the micro climate
  - Univ.-Prof. DDr. H.W. Juergens and Dr. K. Helbig, University Kiel, Germany
- 2) Sleep study 2007
  - The influence of textiles on well being and sleep quality, Univ.-Prof. Dr. Maximilian Moser, Johanneum Research, Institute of Non-Invasive Diagnosis, Austria
- 3) Sensitive skin 2008 – new study
  - „Deutscher Allergie- und Asthmabund“


# Sleep studies: Comparison of different bed set-ups

	„standard“	polyester	TENCEL®
<b>mattress ticking</b>	cotton	polyester	TENCEL® blend
<b>mattress filling</b>	polyester	polyester	TENCEL® blend
<b>bed sheets</b>	cotton	polyester	TENCEL® MICRO
<b>comforter - / pillow filling</b>	polyester	polyester	TENCEL® FILL
<b>shell fabrics</b>	cotton	polyester	TENCEL® MICRO





# Study 1: Comparison of the micro climate

TENCEL® leads to a dry and warm climate in the sleeping cave



# Study 2: Comparison of the autonomic sleep quality index


TENCEL® gives significantly better sleep quality due to optimized thermoregulation.



# Study 3: Sensitive skin study 2008

---

German allergy association (DAAB).



\* “How is skin friendliness [of the TENCEL® product] compared to the usually preferred material?”



# Important aspects for Mattress

---

## Textile:

- Fabric hand
- Washability / Shrinkage
- Wet and dry pilling resistance




## Physiological performance:

- Moisture Management
- Thermoregulation



## Hygiene

Reduced/retarded growth of Fungi  
and dustmite






---

# Enhanced wet and dry pilling resistance in knitted mattress ticking




# TENCEL® Airjet spun yarn in mattress ticking



- Airjet yarns are a significant improvement of the dry and wet pilling behavior
- As smooth as Ring yarn.. Pills less than Open End yarn



# Higher pilling resistance possible



---

# Lenzing research on moisture management and physiological attributes


---

# Enhanced physiological performance



# Short time vapor absorbcency (Fi)


European Standard ISO 11 092: 1993




# Short time vapor absorbency ( $F_i$ )



- TENCEL® shows 4 fold water vapor sorption in comparison to cotton
- Already with 50% TENCEL® the absorbency of 100% cotton is exceeded



# Alambeta: Warm / Cool feeling



TENCEL surface feels cooler





# Water absorption and distribution in fibers



TENCEL® fibers are hydrophilic and hygroscopic and can absorb ~ 70% water. Water is absorbed and transported within the fiber.

Polyester fibers are not hygroscopic and not absorbing. Only 2-3 % water can be adsorbed at the surface.



TENCEL®



Polyester

# TENCEL<sup>®</sup> strongly retards bacterial growth




Bacteria need high amounts of free water (high water activity) for their growth

TENCEL<sup>®</sup> can absorb high amounts of water inside its nano-fibrillar structure

The water activity on humid TENCEL<sup>®</sup> fibers is much lower than on synthetics



Therefore, bacteria find very bad growth conditions on TENCEL<sup>®</sup>



# Vapor condensation at saturated humid climate



Polyester Fiber  
non absorbing  
water adsorbed  
ON surface




TENCEL® Fiber  
water absorbent  
water absorbed  
IN the fiber

Video: water vapor condensation  
on Polyester and TENCEL®



# Cross-sections of Cellulosic Fibers

---



Different size and distribution of pores in Cotton, viscose, Modal and TENCEL® lead to significant differences in the

- amount of absorbed water
- distribution of water over the fiber cross section

# Water transportation on fabric surface



**5 sec**

**30 sec**


**6 min**



**PES**



# Drying rate




Video:  
water vapor absorption  
(swelling) of TENCEL®  
in a blend with PES

- Drying rate depends on water migration speed
- TENCEL dries as fast as cotton
- TENCEL/PES combination dries faster



# Water management means temperature management



- At “Normal” humidity (room) vs. high humidity (bed), the water/cellulose system of TENCEL® has a high heat capacity
- At normal applications, TENCEL® matches the PCM-loaded synthetic fiber

---

# Enhanced hygiene







# Hygiene



retarded bacterial growth without chemistry


no malodor



# Anti-dustmite activity

---

Tested according to the French Norm NF G39011 (2001)



TENCEL®

148\*

dustmite number after 42 days

cotton standard

5880\*

\* Original number of dustmites: 300

Ref: IFTH test report




# Hygiene



- All organisms need water to live !
- A dry environment retards the growth of micro organisms



**Polyester**





**TENCEL®**



# Electrostatic behavior

Electrostatic charge of humans body after a friction experiment with textiles. TENCEL® shows neutral electrostatic properties.


**No electrostatic charge with TENCEL®!**





# Muscle activity measured by Electromyography

before



MM.EXTENSOR CARP. BEFORE TEST DEXTER

RESTING STATE

MM.EXTENSOR CARP. AFTER TEST DEXTER

RESTING STATE

**TENCEL®**

Dr. Malgorzata Zimniewska (Inst. of Natural Fibers, Poznan / PL)  
Prof. Juliusz Huber (Medical University Poznan / PL)



# Conclusion: TENCEL® enhances comfort and hygiene in all mattress components!

---

## **Mattress ticking:**

Softer touch

Enhanced physiological performance

Reduced fungi growth


## **Fiber wadding:**

enhanced humidity management

Reduced fungi and dustmite growth

## **Mattress core:**

Reduced fungi and dustmite growth





# TENCEL® in mattress offers:

- Better humidity and temperature management
- Better hygiene
- Enhanced mattress comfort

More quality with less chemistry

